

# **General Engineering**

for Post Graduate Diploma Course in Industrial Instrumentation & Process Automation (DIIPA) (CANE HANDLING/CANE PREPARATION/MILLING)

by

Vinay Kumar Assistant Professor (Sugar Engineering) National Sugar Institute,

(Govt. of India) Kanpur, Uttar Pradesh

Email : vinay\_ind@yahoo.com



# **Cane Unloading**



#### For a 2500/5000 TCD plant -

Crane gantry : span - 30 metres , length - 40 metres (as per requirement)

Particular	Type of motor	H.P.
Hoisting Drum Drive	Squirrel cage/slip ring induction motor	25-35
Holding Drum Drive	Squirrel cage induction motor	25-35
Long Travel Drive	Slip Ring induction motor	10
Cross Travel Drive	Slip Ring induction motor	7.5



Name of the factory	TCD	Crane parameters
Balrampur Chini Mills Ltd, Balrampur	7000	Span 22 meters x 57 meters Gantry Length
DSM Sugar Mills Ltd. ,Meerganj, Bareilly	5000	Span 24 meters x 80 meters Gantry Length



In a sugar factory cane comes from two modes :

2. Centre Cane- (i) Cane comes in the factory by this mode with the help of Trucks. (ii)Unloaded with the help of tipplers.



# Mode of supply.....examples

Name of the Factory	Capacity (TCD)	Details of mode of supply
DSM Sugar Mills Ltd. ,Meerganj, Bareilly	5000	•Truck - 40 •Carts - 10 •Trolleys - 60
Haryana Cooperative Sugar Ltd. Rohtak	3500	•Truck - <b>30</b> •Carts - <b>18</b> •Trolleys - <b>52</b>



# Sling Bar (hooks & chains)

➢Used for unloading bundled cane from trolleys and truck with the help of rope.







# Grab





#### Hydraulic

Mechanical



# Cane Unloading.....


## Truck Tippler

➢ These are actuated by hydraulic drives which tilt the wagon/truck body resulting cane to slide into the carrier when inclination reaches about 45° to 50°





Factory	Capacity (TCD)	Specifications
AVADH SUGAR & ENERGY LIMITED <b>P.O. Hargaon, Distt.</b> <b>Sitapur</b>	10000	Capacity : <b>50 M.T.</b> Length & Width of platform : 9.5 mtr X 3.3 mtr Tilt angle : <b>55</b> <sup>0</sup>
DSM Sugar Mills Ltd. ,Meerganj, Bareilly	5000	Capacity -40 MTAngle-45°Rating-10-12 Lift/hr





Qty.	3 + 1 = 4
Туре	Grab Hydraulic
Capacity	5Ton Swl
Max. lift	8000
Crane span	23050
Crane overall length	23460
H.P.of hoisting motor	22 KW
Hoisting speed	
M/Min.	12M/min.
HP.of drum holding	
motor	22 KW
Holding speed	
M/Min.	12.0Mtr./Min.
Cross travel speed	
M/Min	23.0M/Min
HP.of cross travel	
motor	5HP.
Crane travel speed	
M/min	23.0M/min.
Cane	
handled(Tons./hour)	145180T./hr.
Bridge Motor	7.5KW, 1 No,955rpm
	5.5 KW , 2 No



# **Cane Carrier**









# **Cane Carrier**


Cane carrier is a moving apron which conveys the cane from cane yard to feed into the mill. It has -

#### 1. Horizontal Portion.

- Length of the horizontal portion depends upon width of feeder tables and the space required for other unloading devices.
- Width of carrier = the length of mill rollers for uniform and effective cane feeding into the mills.

#### 2. Inclined Portion.

- Length : 14 to 17 m (3- roller mill)
- Slope varies from 15 to 22 degree.
- If less than 15° then cost of installation and space occupied will increase.
- If greater than 22° then cane will liable to slip and carrier would move without picking the cane up.






#### **Cane Carrier**

Size, Width and Length between centre	a)	Feeder Cane Carrier (78") Width 1.981 Mtrs x 51.1 Mtrs length driven by 100 H.P. Dynodrive system variable speed 3- 10 meter per minute
	b)	Main Cane Carrier (90") Width 2.286 Mtrs x length 42.5 Meters driven by Dynodrive system of 150 H.P. variable speed 3-10 meters per minute
	c)	Rake Elevator Width 1.981Mtrs x length 18.70 Mtrs with Dynodrive system of 100 H.p. Dynodrive
	d)	Auxiliary cane carrier 3.963 Mtrs wide x 30 Mtrs long with 75 H.P. Dynodrive





#### CANE CARRIER

		1 <sup>st</sup> carrier	2 <sup>nd</sup> carrier	3 <sup>rd</sup> carrier
		(slat convey	or)(Belt convey	vor)(Rake Elevt.)
1.	Width(mm)	2300	2300	2300
2.	Length between the sprocket centres(m)	64m	45m	13m
3.	Horizontal loading length (m)			1000
4.	Angle of inclination( with horizontal)	$17^{0}$	14 <sup>0</sup>	45 <sup>0</sup>
5.	Drive			
	(i)Electric motor			
	(a) Horse power	75KW	30KW	40KW
	(b) Speed(rpm)	1480	1470	1475
	(c) Make			e-manufactures
	(d) Type	V.F.D.	V.F.D.	
	• •			



Cane Carrier.....

## **Bulk density**

Type of Sugarcane	Density in Kg/m <sup>3</sup>
Entangled	150
Loose pile	200
Bundle in pile	250
Mechanically harvested	300
Prepared by 2-knife set	480



- u = 1/2 (peripheral speed of mill roller)
  - =  $1/2 \pi D n$ , where 'n' is rpm of the mill roller

#### <u>Power requirement of Cane - Carrier (u)</u>

The mean power absorbed by the cane carrier is having two components -

- (i) The Power necessary to overcome friction
- (ii) The Power required to elevate the cane

$$P = P_f + P_e$$



## Cane Carrier.....

### The Power necessary to overcome friction

$$P_f = \frac{(Q+K)f + Kf'}{60 \times 75} u \,\lambda$$

#### where,

- $P_f$  = power necessary to overcome friction, in h.p.
- Q = weight of cane on the carrier, in kg
- *K* = half the total weight of the moving part of the carrier

( = weight of the upper or lower run of the conveyor)

- f = coefficient of friction of the upper run (~0.30)
- f' = coefficient of rolling friction of the lower run (~0.15)
- *u* = speed of the conveyor, in m/min

 $\lambda$  = coefficient (~1.4 to 1.5), depending on the efficiency of gearing transmitting the drive.



# Cane Carrier.....

#### The Power necessary to elevate the cane

$$P_e = \frac{1000 \times AH}{3600 \times 75} \ \lambda$$

#### where,

- $P_e$  = power necessary to elevate cane, in h.p.
- A = crushing rate of the mills, in t.c.h.
- *H* = difference in height between the highest part of the carrier and the horizontal part of the carrier in the yard, in m

 $\lambda$  = coefficient (~1.4 to 1.5), depending on the efficiency of gearing transmitting the drive.

$$P = P_f + P_e$$



# **Cane preparation**

- The purpose of cane preparation is to cut cane into short pieces for feeding the mills and to rupture the cells, without extracting juice. This is achieved by set of rotating knives.
- 1<sup>st</sup> Set of Knives (Leveller/Kicker)
   2<sup>nd</sup> Set of Knives
   Fibrisor/Shredder
- Clearance The clearance of a knife set is the distance between the circle desired by the extremity of the knives and the plane passing through the highest portions of carrier.
- Required Preparatory Index 85-90%
- Methods of drive (i) Steam turbine

(ii) Electric Motor (SRIM) – LT or HT motors



#### Cane preparation.....

#### <u>1<sup>st</sup> set of Knives (Leveller/Kicker)</u>


It is required mainly to even out layer of cane. They are arranged to work with high clearance and hence leave large portion of uncut cane.

✓ Power requirement : 10-15 HP/tfh
✓ Pitch : 50mm

#### <u>2<sup>nd</sup> set of Knives :</u>

It is required to further prepare and disintegrate the cane and having clearance lower than 1<sup>st</sup> set of knives.

✓ Power requirement : 20-25 HP/tfh
✓ Pitch : 20-22mm



"pitch" of knives is the mean distance, measured parallel to the axis, separating two successive circles of rotation.



#### Direction of rotation :

- Knives at the lowest part of their rotation will move in the direction corresponding to the movement of the carrier.
- The opposite direction will have better preparation but require more power.

#### **Balancing**:

The knives set should be perfectly balanced to avoid undesirable vibrations.

#### Factors for Power requirement :

- Tonnage of cane
- Fiber in the cane and its nature (more/less resistant)
- Proportion of cane actually cut
- Number of blades
- Speed of rotation
- Radius of cutting circle
- friction, lubrication, wearing f knives





#### **Knives of preparatory Devices:**

#### 1. <u>General Features</u>

 $\succ$  The knife blades are removable, so that they can be easily taken off for resharpening or for replacement by another set of blades.

 $\succ$  It is preferable to fix a knife to the arm in such a way that the edge affected by shocks is supported by a flange or a wide stirrup rather than fixing it so that shocks are absorbed by the bolts or pins securing the knife.

No. of blades/Knives :

N = W/P - 1

Where, W is the width of carrier in cm P is the pitch of Knives in cm

When above eqn. gives an odd number for N, the even number immediately lower is generally adopted;





#### 2. <u>Design/types of knives/blades</u>

#### (i) Reversible Knives

➤ The working life of the blades is prolonged by diminishing wear of the cutting edge.

➢ Producing a self-sharpening effect of the knives on the trailing edge, and so rendering them reversible






#### (ii) Hoe Knives

- The radius of action remain constant with wear
- They have the effect of a transverse cut due to the bent end of the knife and this transverse cut is superimposed on the longitudinal cut made



## (iii) Swinging Knives

➤ These have ability to diminish or reduce the consequences of shocks, by mounting the knives so as to swing on a pin, obtaining at the same time a slight displacement of the cutting points






# **Shredder**

The object of the shredder is to complete the preparation and disintegration of the cane, so as to facilitate the extraction of juice by the mills.

The shredder is placed at the head of the tandem, after the knives and before the first mill.


**Function :** The shredder owes its existence and its value to the fact that the tissue of cane cells is very resistant; simple crushing between rollers, even under very high pressure, is not sufficient to break all the cells and extract the juice. On the other hand, if these cells can be torn open and disintegrated, the juice is liberated, becoming more accessible and more easily extracted. To obtain such an effect it is necessary to rupture the tissues: this is achieved by forcing the pieces of cane to pass through a very narrow space, thus blocking them on one side and striking them on the other side with a powerful blow; the hammer mill has been chosen with this object.

The shredder thus consists of a rotor carrying hammers which are pivoted on discs or plates; the end of the hammer passes very close to an anvil plate which is formed either with a saw-toothed profile





#### Position w.r.t carrier head......






# Milling



The function of Mill is extraction of juice from cane by the effect of pressure.





#### Important terms:

Housing Feed arrangement (Donnelly chute) ➢ Roller Trash plate Grooving  $\blacktriangleright$  Pressure in mills Scrapper  $\succ$  Mill setting Imbibition



# **Three Roller Mill**





The feed and discharge rolls are fixed, while the top roll is free to move up and down by means of a hydraulic pressure system.

Sl.No	Size(D" X L")	TCD (max.)
1	24 x 48	1600
2	30 x 60	2880
3	33 x 66	3890
4	36 x 72	4580
5	40 x 80	5850




# **Grooving of Rollers**

- increases the capacity of the mill
- breaks up the bagasse more completely and thus facilitates the extraction of the juice by the following mill

### <u>Circumfrential Grooves</u>

➢ It is formed by grooving the roller with notches describing complete circles, in planes perpendicular to its axis

- Types
  - Fine : 5-20 mm pitch
  - Medium : 20-25 mm
  - Coarse : > 50mm








## Messcharet Grooves

The grooving mainly adopted on feed rollers is also known by Messchaerts or Juice grooves. The only objective of such grooving is improvement of extraction. Special scrappers or combs are fitted so that the grooves are kept free of the bagasse.





# **Chevron Grooves**


Such kind of grooving is adopted for basically griping on bagasse so that we can achieve improvement in feeding of bagasse. Chevron is placed only on two feeding rollers i.e. on top roller and on feed roller.





## Lotus Rollers

Messchaert grooves cannot be used in top rolls because there would be no easy outlet for the juice except into the bagasse exiting the mill. They would also seriously weaken the roll that is most highly stressed and most frequently broken. Drainage from the upper surface of the bagasse passing through the mill is indeed a major problem, since the juice must flow in the roots of the grooves all the way back to before the first squeeze. This problem prompted the "Lotus roll" concept of providing an alternative drainage passage from the top roll.







# Mill feeding


Cane preparation coupled with high levels of imbibition render gripping of bagasse extremely difficult resulted development of new feeding methods had to overcome the mill feeding problem like Donelly chute,GRPF, TRPF, etc.

#### **Donnelly chute**

In the gravity feed system closed feed chute is provided at an angle of 75° to 90° to the horizontal. The inner parts of this chute viz. the side plates have to be very smooth and are preferably of stainless steel to avoid frictional resistance and for easy flow of bagasse or prepared cane. It is usually provided at the first mill, where cane preparation is fine.

#### **Underfeed rollers**

The underfeed rollers usually are of cast iron and grooved, with diameters half to two thirds of the mill roller diameter. The drive for these rollers is provided from the mill rollers by pinion or chain. The peripheral speed is about 10% higher than that of the mill to which it is attached. These feed rollers require low power (5-10 hp.) and helps improve capacity and extraction of mills.





#### **Continuous pressure**

(i) GRPF : This feeder consists of a pair of rollers mounted ahead of the mill and connected to the mill by closed chute of stainless steel, which has some what more opening towards the mill. These rolls extract good amount of juice reducing the load on the mill and rendering gripping action easy. The speed of these rollers is about 30-70% higher than that of the mill. They give positive improvement in capacity and extraction as they permit of addition of high imbibition and fine

(ii) **TRPF**: Toothed rings are fitted to rollers and are welded with hard faced electrodes for maintaining their condition as their wear affects the performance. The toothed rollers push the bagasse blanket towards the mill and provide more positive feed. The power requirement of toothed rollers is about half that for GRPF.

